



TF097: DISCRETE WINCH MOUNT

DISCOVERY 3, DISCOVERY 4 & RANGE ROVER SORT

FITTING INSTRUCTIONS

Please note that certain winches may require the clutch release handle to be moved or modified



Prior to removing parts from your vehicle fit the winch into the mount.

Place fairlead extension onto the mount and bolt into place using the 2 x internally threaded spacers.

Remove winch electrics prior to fitting (make a note of wiring positions for the motor and refer to winch manual)

Fit your winch into the mount

Remove the front grill from the vehicle. Refer to Owner Handbook.

Press the 4 top clips and pull forwards

Release the 2 lower clips and pull the grill forwards

Remove headlights by lifting the 2 clips to align the hole with the pin.

When both clips are released pull the light forward and unplug the electrical connector.

Remove the screws on the wheel arch flares on both sides.

Remove the plastic panel.

Remove the screws along the top of the bumper and the 4 bolts from underneath, then remove the end screws.

Be careful not to break these.

WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defacts in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or markted by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with or application, modified product faulty design or consequential damage on ykind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes I.d. The information contained in this calalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications. Without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma ange of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.

THANKS FOR CHOOSING TERRAFIRMA – SERIOUS 4X4 ACCESSORIES

TF097

D3 / D4 / RRS





Gently pull the flare away and undo the remaining bolts on both sides of the bumper. Then push the clips back on either side to completely remove the bumper from the vehicle.

Remove the 2 bolts that secure the washer bottle and remove the air control unit by pushing in an upwards motion.

Remove the 8 bolts from the inner bumper reinforcement and take it off the chassis.



Remove the Air temperature sensor by unscrewing the 2 screws under the engine bay, reposition this.

Use assistance to lift the winch mount containing the winch into place so it may be bolted to the chassis.

If the chassis has 8mm captive nuts drill out and replace with M10 plates supplied

When mount is in position measure and scribe the grill so it may be trimmed precisely to the fairlead.

On the nearside two outer M10 bolts fit the retaining plate for the washer bottle.

On the two offside outer bolts fit the plate for the winch electrics and air control unit.

Loosely attach the winch mount to the inner bumper reinforcement using the 8 x spacers

provided. Once the mount is in the correct position, tighten all 8 bolts.

Replace winch electrics (refer to your prior notes or winch user manual) You may need extended cables.



Installation for D4 and RRS are fundamentally the same as above

WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defacts in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or markteded by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with callaws. This warranty covers structural defect and workmanship but does not ocver finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to any other purpose other than normal private usage are not covered by this warranty. Terrafirma hall not be liable for any other other than normal private usage are not covered by this warranty. Terrafirma hall not be liable for any other other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes I.d. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications. Without notice. Always consult your Allmakes/Terrafirma and is associated for enhancement and improvement to make sure the level of quality and performance is as expected.

THANKS FOR CHOOSING TERRAFIRMA – SERIOUS 4X4 ACCESSORIES

TF097

D3 / D4 / RRS