



TF143: TERRAFIRMA COMMERCIAL HD SHOCK ABSORBER – STANDARD TRAVEL – REAR

DEFENDER 90 / 110 / 130, DISCOVERY 1 & RANGE ROVER CLASSIC

FITTING INSTRUCTIONS

1. Put the car into gear and apply the hand brake, loosen rear wheel nuts, raise vehicle on a jack and then support the rear axle on axle stands.
2. Remove the rear wheels.
3. Undo the nut on the bottom of the shock absorber remove all bushes and washers.
4. Undo the nut on the top shock absorber chassis mount and then pull the shock absorber off of the mounting removing all bushes and washers.
5. Fit the new shock over the top chassis mounting, with the new washers and bushes in the correct order and the correct way around, the convex side of the curved washers must be against the rubber bush, and then tighten the top nut.
6. Fit the upper bottom washers and bush, before pulling the lower part of the shock absorber down through the axle mounting bracket *. Then fit the lower bottom washers and bush and the securing nut, Tighten the bottom securing nut.
7. When both sides are done refit wheels lower the car off of the axle stands and torque the wheel nuts correctly.
8. 4-stage adjustable shocks are designed with an adjustable knob at the lower end of the body that allows you to configure your ride depending on your needs and your desired comfort. No.1 is the softest comfort setting increasing to No. 4 for the firmest sport setting.
 - **IMPORTANT** – It is essential to remove the two metal bush cups found on post 1994 Defenders and Discovery rear axles at the lower axle shock mounting bracket, this will allow unrestricted movement of the lower shock mount.
 - Ensure the two domed machined top mounting washers are fitted the correct way around with the domed surface against the rubber bush.
 - Allowing the flat side of the top shock washers to bind against the shock absorber eye can cause premature shock failure and invalidate the warranty
 - Allowing the shock bush washers to contact the metal bush cup can cause premature shock failure and invalidate the warranty



WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fitment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ltd. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.