



TF705: TERRAFIRMA ROUND 25W CREE LED 1800Lm SPOTLIGHT KIT

NON VEHICLE SPECIFIC

FITTING INSTRUCTIONS

- 1. Put the car into gear or park and apply the hand brake.
- 2. Terrafirma LED lights should be mounted to a flat surface.
- 3. Drill the correct size hole and securely bolt them to the required surface.
- 4. A full wiring harness is supplied to connect the lights to a power source via a dash mounted switch.

Transfer of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with focal laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fitment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirms shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4Terrafirma distributor. This warranty covers only the replacement of the product or part the range and any product specifications without notice. Always consult your Allmakes Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.