



TF528: TERRAFIRMA CASTOR CORRECTED FRONT RADIUS ARMS

6 DEGREE FOR LIFTS IN EXCESS OF 2"

DEFENDER 90 / 110 / 130, DISCOVERY 1 & RANGE ROVER CLASSIC

FITTING INSTRUCTIONS

1. Put the car into gear or park and apply the hand brake, loosen the front wheel nuts on one side, raise the vehicle on a trolley or bottle jack under the axle and then support the vehicle with an axle stand under the chassis. It's easier and safer to do this job one side at a time.
2. Remove the front wheel.
3. Lower the car so the axle stand takes most of the cars weight but leave the jack under the axle to support the axle's weight.
4. Clean all 3 mountings nuts and bolts and treat with a penetrating fluid if necessary.
5. Undo and remove the rearmost (chassis end) nut and mounting bush.
6. Remove the split pin, then loosen and remove the nut and washer securing the track rod ball-joint to the swivel housing. Then remove the ball joint from the tapered hole on the rear of the swivel housing.
7. Slacken and remove the nuts and bolts retaining the radius arm to the axle, It is recommended that if the bolts are worn they should be replaced.
8. Drop the radius arm down and out of the axle brackets and then pull the back end forwards through the chassis bracket.
9. Take your new castor corrected radius arm with the new bushes you have fitted in the axle end, fit the first of the chassis end washers bushes and then push the arm through the chassis mount from the front.
10. Lift the axle end up into the brackets and re-fit the bolts and nuts loosely.
11. Re-connect the track rod ball joint to the tapered hole in the swivel housing, tighten up the nut to the correct torque setting and then fit a new split pin.
12. Slide the second, rear most mounting bush then the washer and nut on from the back side of the chassis mounting and tighten the nut to the correct torque setting.
13. Tighten the two axle end mounting bolts up to the correct torque setting.
14. Refit the wheel, lower the car off of the axle stand and torque the wheel nuts correctly.
15. Repeat the procedure on the other side of the car.
16. **NOTE: these arms are supplied without bushes to enable you to fit the replacement bush of your choice, including TF polyurethane bushes.**

WARRANTY & DISCLAIMER - Terrafirma products are warranted free from defects in materials and workmanship for a period of 12 months from the date of retail invoice. Terrafirma does not warrant that the products manufactured or marketed by it comply with the laws of the country where those goods are purchased or used. It is the sole responsibility of the purchaser to ascertain whether products being purchased, or the fitting of those products to any other object, comply with local laws. This warranty covers structural defect and workmanship but does not cover finishes, labour charges for removal or refitting, freight costs, accident damage, misuse or abuse, damage due to incorrect or improper fitment or application, modified product, faulty design or consequential damage of any kind. Damage or defects caused by collision, alteration, improper installation, road hazards, adverse conditions or usage for any other purpose other than normal private usage are not covered by this warranty. Terrafirma shall not be liable for any other claim relating to the use of the product and any indirect special or consequential damage or injury to any person, company or other entity. All claims must be accompanied by the original retail invoice and should be submitted to the supplying Allmakes 4x4/Terrafirma distributor. This warranty covers only the replacement of the product or part concerned. The decision remains solely at the discretion of Allmakes Ltd. The information contained in this catalogue was correct at the time of going to press. Allmakes/Terrafirma and its associated companies reserve the right to alter the range and any product specifications without notice. Always consult your Allmakes/Terrafirma distributor for the latest product information and specifications. The Terrafirma range of products is constantly being evaluated for enhancement and improvement to make sure the level of quality and performance is as expected.